

What's in the box:

- Quick start guide
- ConnectCore Wi-i.MX51 module - 800 MHz i.MX515, 512 MB NAND Flash, 512 MB DDR2, 0° C to +70° C
- 7" WVGA LCD panel with touchscreen
- Digi JumpStart Kit development board  
3 serial ports (1 x RS-232/422/485, 1 x RS-232 Tx/Rx, 1 x TTL), VGA, HDMI 1.3, Ethernet (RJ-45), WLAN antenna connectors, SD/MMC slot, MicroSD slot, USB OTG, 4 x USB Host, I2C/SPI headers, 1-Wire connector, audio: line in/out and microphone in (3.5 mm), Digi XBee module socket (module sold separately), GPIO screw terminal, user push-buttons, user LEDs, battery, 802.3af (PoE) module socket (module sold separately), external LCD/Touchscreen connectors, external camera connectors, user/application connectors, JTAG connector, 9-30VDC power supply, power switch
- Digi Embedded Linux DVD
  - Digi Embedded Linux, Digi ESP IDE, BSP source code, boot loader source code, sample code
- Documentation and development board schematics
- Power supply and accessories
  - External wall power supply with adapters, Ethernet cable, antennas, serial cable